

Gas Lift

Quick fix and service guide

Quick fix / maintenance guide

During use and aging the properties of a gas lift changes. Typical symptoms are tardy movement, or that the lift raises when the chair is not used.

The main reason for this is lack of cleaning and lubrication in particular if the height is rarely adjusted.

Here are a few easy tips that may repair gas lifts with reduced performance. We recommend that these steps are repeated as periodic maintenance to avoid problems.

Step 1

- **a.** Set the chair in the highest position.
- **b.** Use a rag/cloth to remove dirt and old grease.
- **c.** Apply a thin layer of new grease.



Lubricant

Any soap-based grease may be used.

If necessary it is also available from Flokk: Article #149205



Step 2

- **a.** Release the lift by using the release mechanism.
- **b.** Lower and raise the the seat completely 10 times while keeping the lift in release mode.

