

HOW TO ADJUST YOUR RH EXTEND

PERFORMANCE • DESIGNED FOR HUMAN

1



HEIGHT OF THE CHAIR

2



BACKREST ANGLE

3



SEAT DEPTH

4



BACKREST HEIGHT

5



UNLOCK THE DYNAMIC
TILT

6



TILT RESISTANCE

7



HEIGHT OF ARMREST

8



NECKREST

9



INTERACTIVE USER
INSTRUCTION

