



DESIGNED FOR HUMAN PERFORMANCE

RH LOGIC 400/300

An RH chair is the perfect work tool, a chair that puts you in an optimal position all day, every day. A few simple adjustments is all it takes to make your RH chair fit your individual anatomy. RH chairs support an upright posture and active sitting, increasing your performance.

You deserve a chair that is right for your body. With RH Logic, you can choose a high or low back and a number of other design features. The result is a comfortable chair that helps you to perform better throughout the working day. RH Logic is also available as a 24/7 and ESD friendly chair.

Ergonomics

Providing complete support in any working position, enabling you to always sit correctly and breathe properly.

- Sculptured seat with waterfall front, combined with a tapered back featuring clear lumbar support and "Tvedt" cushion encourages movement and an upright posture.
- Adjustable back angle and infinitely adjustable tilt mechanism that can be locked in any chosen position.
- Pictograms on all handles and levers make the chair easy to use, easy to understand.
- Easily interchangeable seat and back that can be clicked on and off.
- Woollen layer in seat and back ensures improved ventilation, keeping you cooler and more comfortable.
- Inflatable lumbar support gives excellent support for the entire back in an upright posture.

Quality

- 10 year guarantee

Flokk is certified in accordance to:

- ISO 9001
- ISO 14001

RH Logic is certified in accordance to:

- EN 1335-1-2-3 A
- Möbelfakta
- BS 5459/2
- IEC 61340 (ESD)

Environment

- Supports companies' environmental profile and credibility (CSR) - Cradle to cradle proof
- Easy to disassemble and no harmful chemicals
- ISO 14025 (EPD)
- The Nordic Swan
- GREENGUARD

Design

Materials and surfaces communicating comfort and wellbeing through bodyfitting forms. Expressing human performance.

Fire classifications

Foams and standard fabrics are tested to BS/EN 1021-1&2 (cigarette & match). Foam and fabric according to BS-5852 ignition source 5 (crib 5) can be delivered on request. Please contact our customer service for further information.

Maintenance

Vacuum clean the chair with a furniture brush or wipe it with a clean cloth or sponge slightly dampened with lukewarm clean water. Do not remove any plastic parts or attempt to open the seating mechanism. Contact your Flokk dealer if the chair requires servicing or maintenance.

See <https://info.flokk.com/global/rh/user-guide> for RH Logic interactive user instruction guide.





RH LOGIC 300



RH LOGIC 300
COMFORT



RH LOGIC 300
ELITE



RH LOGIC 400



RH LOGIC 400
ELEGANCE



RH LOGIC 400
ELITE

CHAIR MODELS AVAILABLE

RH LOGIC 300

- STANDARD
- COMFORT – Extra padding with improved ventilation in seat and backpad
- ELEGANCE – Including upholstered backshell
- ELITE – 200 mm extra padding and improved ventilation in seat and backpad
- ESD

RH LOGIC 400

- STANDARD
- COMFORT – Extra padding with improved ventilation in seat and backpad
- ELEGANCE – Including upholstered backshell
- ELITE – 200 mm extra padding and improved ventilation in seat and backpad
- ESD

MEASUREMENTS

| | RH LOGIC 300 | RH LOGIC 300 ELITE | RH LOGIC 400 | RH LOGIC 400 ELITE |
|---|--------------|--------------------|--------------|--------------------|
| Seat depth with seat slide | 394-522 mm | 394-522 mm | 394-522 mm | 394-522 mm |
| Seat depth | 465 mm | 465 mm | 465 mm | 465 mm |
| Seat width | 457 mm | 457 mm | 457 mm | 457 mm |
| Seat height - standard gas stem | 410-530 mm | 430-550 mm | 410-530 mm | 430-550 mm |
| Seat angle adjustment | +4,5°-17,2° | +4,5°-17,2° | +4,5°-17,2° | +4,5°-17,2° |
| Height of lumbar support above the seat | 170-255 mm | 170-255 mm | 170-255 mm | 170-255 mm |
| Backrest height | 510 mm | 510 mm | 620 mm | 620 mm |
| Backrest height adjustment (from seat) | 519-598 mm | 499-578 mm | 604-683 mm | 624-703 mm |
| Backrest width | 447 mm | 447 mm | 447 mm | 447 mm |
| Back angle adjustment | 15,2° | 15,2° | 15,2° | 15,2° |
| Height of armrest above seat | 200-300 mm | 170-270 mm | 200-300 mm | 170-270 mm |
| Distance between armrests | 375-576 mm | 375-576 mm | 375-576 mm | 375-576 mm |
| Diameter of base | 660 mm | 660 mm | 660 mm | 660 mm |

OPTIONS

- | | |
|--|---------------------------------------|
| 1 Neckrest (not available for ESD) | 8 Extra large seat |
| 2 Coat-hanger | 9 Decorative stitching |
| 3 Armrest 8E, depth, grey or black | 10 Castors for hard floors |
| 4 Armrest 8S, rotating, grey or black | 11 Castors for soft floors |
| 5 Armrest 8E black/ESD, depth | 12 Base 5X, polished aluminium |
| 6 Armrest 8S XL, rotating, grey or black | 13 Base 5X, black lacquered aluminium |
| 7 Exchangeable pads | 14 Base 5X, grey lacquered aluminium |

GAS STEMS

- 4Q, (standard) Silver or Black, approx 410-530 mm
- B, Silver or Black, approx 480-610 mm
- A, Silver or Black, approx 495-625 mm

For other options see the RH Price List.

The design and specifications of RH Chairs' products are developed on an ongoing basis and the above formulations should not be perceived as completely final.

ESD

RH Logic is available as an ESD chair. Flokk provides a 5 year warranty for ESD, conditional on castors and treads being cleaned regularly with a suitable cleaning agent.

The chairs are approved in line with IEC 61340(ESD). To work effectively the chair should be used in an ESD-adapted environment.