FACTSHEET

RH EXTEND





This elegant chair is as user-friendly as it is ergonomic. RH Extend is designed to give your body the best possible support and relaxation, while at the same time encouraging you to move around. RH Extend is easily adjustable to give everyone a unique working position. All RH Extend chairs are also available in ESD editions.

ERGONOMICS

Providing complete support in any working position, enabling you to always sit correctly and breathe properly.

- Sculptured seat with waterfall front, combined with a tapered back featuring clear lumbar support and "Tvedt" cushion encourages movement and an upright posture. A user-friendly multiuser chair.
- Infinitely adjustable synchro-tilt mechanism, with a smooth action that can be locked in any chosen position.
- Interchangeable seat and back, easy to change (click on click off).

QUALITY

- 10 year guarantee

Flokk is certified in accordance to:

- ISO 9001
- ISO 14001

RH Extend is certified in accordance to:

- EN 1335-1-2-3
- Möbelfakta
- BS 5459/2
- IEC 61340 (ESD)

ENVIRONMENT

- Supports companies' environmental profile and credibility (CSR) - Cradle to cradle proof
- Easy to disassemble and no harmful chemicals
- ISO 14025 (EPD)
- GREENGUARD

DESIGN

Materials and surfaces communicating comfort and wellbeing through bodyfitting forms. Expressing human performance.

FIRE CLASSIFICATIONS

Foams and standard fabrics are tested to BS/EN 1021–1&2 (cigarette & match). Foam and fabric according to BS-5852 ignition source 5 (crib 5) can be delivered on request. Please contact our customer service for further information.

MAINTENANCE

Vacuum clean the chair with a furniture brush or wipe it with a clean cloth or sponge slightly dampened with lukewarm clean water. Do not remove any plastic parts or attempt to open the seating mechanism. Contact your Flokk dealer if the chair requires servicing or maintenance.

See https://info.flokk.com/global/rh/user-guide for RH Extend interactive user instruction guide.

GREENGUARD

MÖBELFAKTA

epd

GUARANTEE 10 YEAR GUARANTEE

Normal use up to 9 hours/day



RH EXTEND 100



RH EXTEND 120



RH EXTEND 200



RH EXTEND 220

CHAIR MODELS AVAILABLE:

RH EXTEND

- 100 – Medium back
- 120 – High back
- 200 – Medium back, with tilt mechanism and backrest that can be adjusted separately.
- 220 – High back, with tilt mechanism and backrest that can be adjusted separately.
- 200 ESD – Medium back, with tilt mechanism.
- 220 ESD – High back, with tilt mechanism.

MEASUREMENTS	RH EXTEND 100	RH EXTEND 120	RH EXTEND 200	RH EXTEND 220
Seat depth with seat slide	432-518 mm	432-518 mm	432-518mm	432-518 mm
Seat depth	444 mm	444 mm	444 mm	444 mm
Seat width	462 mm	462 mm	462 mm	462 mm
Seat Height - standard gas stem	420-534 mm	420-534 mm	420-534 mm	420-534 mm
Seat angle adjustment	-12°-(+)6,5°	-12°-(+)6,5°	-12°-(+)6,5°	-12°-(+)6,5°
Height of lumbar support above the seat	150-250 mm	150-260 mm	150-250 mm	150-260 mm
Backrest height	510 mm	627 mm	510 mm	627 mm
Backrest height adjustment (from seat)	528-587 mm	645-704 mm	528-587 mm	645-704 mm
Backrest width	413 mm	423 mm	413 mm	423 mm
Back angle adjustment	-	24°	-	24°
Height of armrest above seat	205-305 mm	205-305 mm	205-305 mm	205-305 mm
Distance between armrests	409-529 mm	409-529 mm	409-529 mm	409-529 mm
Diameter of base	700 mm	700 mm	700 mm	700 mm

OPTIONS

1 Neckrest
2 Coat-hanger
3 Exchangeable pad
4 Decorative stitching
5 Extra-large seat
6 Armrest 8E (height, depth, width)
7 Armrest 8S (height, width, rotating)
8 Armrest 8E Black/ESD, depth-adjustable
9 Castors for hard floors
10 Castors for soft floors
11 Base 5X polished aluminium
12 Base 5X black lacquered aluminium
13 Base 5X grey lacquered aluminium
14 Uniform upholstery

GAS STEMS

4Q, silver (standard), approx.	420-534 mm
4Q, black, approx.	420-534 mm
B, approx.	490-630 mm
A, approx.	535-670 mm

For other options see the RH Price List.
The design and specifications of RHs' products are developed on an ongoing basis and the above formulations should not be perceived as completely final.

ESD

RH Extend is available as an ESD chair. Flokk provides a 5 year warranty for ESD, conditional on castors and treads being cleaned regularly with a suitable cleaning agent.

The chairs are approved in line with IEC 61340(ESD). To work effectively the chair should be used in an ESD-adapted environment.